

## Conference Page

The conference page is an overview of the system and is designed to be used in a conference to give quick access to the most used functions within the system.

### Program Video

These buttons are used to select what video you would like to display within the meeting room.



### Mics

These buttons allow tweaking of individual mic's within the meeting room.



### Connection Status

This shows the connection is working with the Bose unit



### System off

After the meeting has finished press this to turn the room off.

## Microphone Page

The microphone page gives you control over all the mics in the room.

Mic Name

**BOSE**

PROFESSIONAL

CONFERENCE

MICROPHONES

VOIP

PSTN

COMBINE

SYSTEM  
OFF

MIC 1

MIC 2

MIC 3

MIC 4

MIC 5

MIC 6

MIC 7

MIC 8

+

+

+

+

+

+

+

+



-

-

-

-

-

-

-

-

MUTE

MUTE

MUTE

MUTE

MUTE

MUTE

MUTE

MUTE

● Connection  
Status

ROOM 1

### Mic Bargraph

Drag the bargraph up and down to make quick changes to the level.

### Mic Level

Percentage level the mic is currently at.

### Mic Mute

Press this to toggle the mic mute on and off.

### Mics Up and down

Tweek the mic level up and down using these buttons.

## VoIP Page

The VoIP page allows you to make calls and adjust the call levels when in the call.

### Call Status

Displays the current call state.

### Transmitting Volume

Volume of audio you are sending to the participants at the far end.

### Dialer

Allows number input for call control

### Privacy

Mute all outgoing audio to VoIP call.

### Phone Book

Phone book of pre-stored phone numbers.

### Local Audio

Audio level of far end in room.

### Re-Dial

Re-Dials the previous number dialed.

### Auto Answer

Auto answers incoming calls.

The VoIP page interface is divided into several sections:

- Header:** Includes the **BOSE** logo, **PROFESSIONAL** branding, and navigation tabs for **CONFERENCE**, **MICROPHONES**, **VOIP** (selected), **PSTN**, and **COMBINE**. A **SYSTEM OFF** indicator is in the top right.
- Call Status:** Displays **CALL STATUS :: INCOMING**.
- Dialer:** A numeric keypad (0-9, \*, #) and function buttons: **DEL**, **C**, **DIAL** (green), **HANG UP** (red), **RE-DIAL**, **AUTO ANSWER**, **PRIVACY**, and **PHONE BOOK**.
- Volume Controls:** Two vertical sliders for **TRANSMITTING VOLUME LEVEL** and **RECEIVING VOLUME LEVEL**. Both are set to 50%. Each slider has **+** and **-** buttons and a **MUTE** button at the bottom.
- Footer:** A **Connection Status** indicator (red dot) and the room name **ROOM 1**.

Red arrows point from the external labels to the corresponding UI elements: Call Status to the status text, Dialer to the numeric keypad, Privacy to the PRIVACY button, Phone Book to the PHONE BOOK button, Transmitting Volume to the transmitting slider, Local Audio to the receiving slider, Re-Dial to the RE-DIAL button, and Auto Answer to the AUTO ANSWER button.

**Call Status**

Displays the current call state.

**Dialer**

Allows number input for call control

**Privacy**

Mute all outgoing to the PSTN call.

**Phone Book**

Phone book of pre-stored phone numbers.

**PSTN Page**

The PSTN page allows you to make calls and adjust the call levels when in the call.

**Transmitting Volume**

Volume of audio you are sending to the participants at the far end.

**Local Audio**


Audio level of far end in room.

**Re-Dial**

Re-Dials the previous number dialed.

**Auto Answer**

Auto answers incoming calls.

**PROFESSIONAL**

**CONFERENCE****MICROPHONES****VOIP****PSTN****COMBINE**

CALL STATUS :: INCOMING

0123456789

1

2

3

4

5

6

7

8

9

\*

0

+

DEL

C

DIAL

HANG UP

RE-DIAL

AUTO ANSWER

PRIVACY

PHONE BOOK

TRANSMITTING VOLUME LEVEL

+

+

50 %

-

MUTE

RECEIVING VOLUME LEVEL


+

+

50 %

-

MUTE

 **Connection Status**

**ROOM 1**

### Incomming Call Popup

This window is displayed when you have an incomming call to the room.

#### Caller ID


Displays the current call ID.

#### Reject

Reject the incomming call.

#### Answer

Answer the incomming call




## Phone Book

The phone book is displayed when the relevant button is pressed on the dialer page.

### Phone Book Entry

Select the phone book entry to populate the number into the dial box.



### Arrow Keys

Use the arrow keys to scroll through the phone book.

## Combine Page

The combine page allows you to combine room to make one large conference room.

### Room Select

When your rooms are combined use the room buttons to select which rooms equipment you want to use.

**BOSE** PROFESSIONAL

**ROOMS COMBINED** ROOM 2 AND ROOM 3  
SELECT ROOM TO CONTROL

SYSTEM OFF

CONFERENCE MICROPHONES VOIP PSTN COMBINE

**ROOM COMBINE VIA CRR**

ROOM 1 COMBINE ROOM 2 UNCOMBINE ROOM 3

**ROOM COMBINE VIA PRESET RECALL**

ROOM 1 COMBINE ROOM 2 UNCOMBINE ROOM 3

Connection Status

**ROOM 2 + ROOM 3**

### Room Combine

Press this button to combine two rooms together. Red indicates that the rooms are combined.

Press the combine room button again to uncombine the rooms.

### Room Names

Both room names are now shown.