

Conference

**Conference Page**

The conference page is a overview of the system and is designed to be used in a conference to give quick access to the most used functions within the system.

**Program Video**

These buttons are used to select what video you would like to display within the meeting room.

**Mics**

These buttons allow tweeking of individual mics within the meeting room.

**Connection Status**

This shows the connection is working with the Bose system.

**BOSE**

PROFESSIONAL

Combined Rooms: Room 1 Room 2

**SYSTEM DEFAULT**

**CONFERENCE**

**MICROPHONES**

**VoIP**

**PSTN**

**COMBINE**

**VIDEO SOURCE**

ROOM PC

B.Y.O.D

STREAM

FAR END

BLU-RAY

CAMERA

**MICS**

Mic 01

+

MUTE

-

Mic 02

+

MUTE

-

Mic 03

+

MUTE

-

Mic 04

+

MUTE

-

Mic 05

+

MUTE

-

Mic 06

+

MUTE

-

Mic 07

+

MUTE

-

Mic 08

+

MUTE

-

PROG

+

83%

MUTE

VoIP Hanging Up

+

55%

MUTE

PSTN

+

33%

MUTE

USB

+

0%


MUTE

MASTER

+

11%

MUTE

 **Connection Status**

**ROOM 1**

**System off**

After the meeting has finished press this to turn the room off.

**In Call Status**

Feedback to show that the system is in a call. Use the + and - buttons to control the volume.

**Level Adjustment**

Use the + and - buttons or bargraph to change the volume level in the room.

**Room Name**

The current room you are in

Exported from Pencil - Fri Jul 05 2019 13:28:39 GMT+0100 (GMT Summer Time) - Page 1 of 7

# Microphones

Microphone Page

The microphone page gives you control over all the mics in the room.

Mic Name

BOSE

PROFESSIONAL

Combined Rooms: Room 1 Room 2

SYSTEM DEFAULT

CONFERENCE

MICROPHONES

VoIP

PSTN

COMBINE

MIC 01

MIC 02

MIC 03

MIC 04

MIC 05

MIC 06

MIC 07

MIC 08

Mics Up and down

Tweak the mic level up and down using these buttons.

Mic Bargraph

Drag the bargraph up and down to make quick changes to the level.

Mic Mute

Press this to toggle the mic mute on and off.

Mic Level

Percentage level the mic is currently at.

51%

54%

63%

81%

42%


25%

29%


58%

Connection Status

ROOM 1



## PSTN



Incoming Call

**Incoming Call Popup**

This window is displayed when you have an incoming call to the room.

**Reject**

Reject the incoming call.

**REJECT**

**ANSWER**

**Answer**

Answer the incoming call

BOSE

PROFESSIONAL

CONFERENCE

MICROPHONES

VIDEO

PSTN

COMBINE

SYSTEM DEFAULT

**INCOMING CALL**

1

4

7

+

Rx VOLUME

63%

83%

PSTN

ROOM 1

Exported from Pencil - Fri Jul 05 2019 13:28:39 GMT+0100 (GMT Summer Time) - Page 5 of 7

# Address Book

**Phone Book**

The phone book is displayed when the relevent button is pressed on the dialer page.

**Phone Book Entry**

Select the phone book entry to populate the number into the dial box.

Combine

Combine Page

The combine page allows you to combine rooms to make one large conference room.

BOSE

PROFESSIONAL

Combined Rooms: Room 1 Room 2

SYSTEM

DEFAULT

CONFERENCE

MICROPHONES

VoIP

PSTN

COMBINE

Room Select

When the rooms are combined, use the rooms buttons to select which room to control

CRR Room Combine

Press the Join button to combine two rooms together. Green indicates that the rooms are combined.

Press the Break button to uncombine the rooms.

COMBINE VIA CRR

ROOM ONE

BREAK

ROOM TWO

JOIN

ROOM THREE

COMBINE VIA PRESET

ROOM ONE

BREAK

ROOM TWO

JOIN

ROOM THREE

Connection Status

ROOM 1

Preset Room Combine

Press the Join button to combine two rooms together. Green indicates that the rooms are combined.

Press the Break button to uncombine the rooms.