



P1

Also required\*  


# SoundXtra

SDXBST30FS1011/1021 Floor Stand for Bose SoundTouch 30

-  x1
- A**  
 x4
- B**  
 x4
- C**  
 x4
- D**  
 x4
- E**  
 x4
- F**  
 x2



\* Zusätzlich wird benötigt \* Également requis \* También se requiere \* Si richiedono inoltre \* Дополнительно необходимо \* Ook vereist \* lisäksi tarvitaan \* Dodatkowo wymagane \* Dessutom behövs \* 还需要

P2

Also required\*



# SoundXtra

SDXBST30FS1011/1021 Floor Stand for Bose SoundTouch 30

4

