

SoundLink®
on-ear Bluetooth® headphones

Quick Start Guide • Quick Start Guide • Quick Start Guide • Quick Start Guide • Quick Start
Guide • Quick Start Guide • Quick Start Guide • Quick Start Guide • Quick Start Guide



English | Danish | German | Dutch | Spanish | Finnish | French | Italian | Hungarian



United States	888 587 2673	Austria.....	www.bose.at
Australia	1800 061 046	Belgium	www.bosebelgium.be
Canada	877 335 2073	Denmark.....	www.bose.dk
China	86 400 880 2266	Finland.....	www.bose.fi
Germany.....	0800 2673 444	France	www.bose.fr
Hong Kong	852 2123 9000	Hungary.....	www.bose.hu
Hungary.....	6040434 31	Ireland.....	www.bose.ie
India	1800 11 2673	Luxembourg.....	www.bose.lu
Italy	800 83 22 77	Netherlands.....	www.bose.nl
Japan	0570 080 021	Norway.....	www.bose.no
Latin Markets, Other	508 614 6000	Poland.....	www.bose.pl
Mexico.....	001 866 693 2673	Sweden.....	www.bose.se
New Zealand.....	0800 501 511	Switzerland.....	www.bose.ch
Taiwan.....	886 2 2514 7977		
United Arab Emirates	800 2673		
UK	0800 279 7347		

For additional countries, please visit
<http://global.Bose.com>

? <http://global.Bose.com>
U.S. only: <http://owners.Bose.com/SoundLinkOE>
Youtube.com/Bose



Bluetooth® wireless technology works with | La technologie sans fil Bluetooth® fonctionne avec
iPhone 5s, iPhone 5c, iPhone 5, iPhone 4s, iPhone 4, iPhone 3GS, iPad Air, iPad (3rd and 4th generation),
iPad 2, iPad, iPad mini with Retina display, iPad mini, and iPod touch (2nd through 5th generation).

For Your Records
The serial number is located on the warranty card included in the carton.
Serial number: _____

Please keep your receipt with the owner's guide. Now is a good time to register your headphones. You can do this easily by going to <http://global.Bose.com/register>.

The warranty information provided with this product does not apply in Australia and New Zealand.
See our website at www.bose.com.au/warranty or www.bose.co.nz/warranty for details of the Australia and New Zealand warranty.



722305-0010

BOSE
Better sound through research®
©2014 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM722305 Rev.00

ENGLISH

Please read and follow this Quick Start Guide and the Important Safety Information and keep for future reference.

Pairing a mobile device

- Slide the Power/Bluetooth® button **D** all the way up to the **F** symbol and hold until you hear, "Ready to pair" or you see the Bluetooth indicator blinking blue. **D F**
- On your mobile device, turn on Bluetooth functionality. Select **Bose OE SoundLink** in your mobile device's Bluetooth list. You will hear, "Connected to <device name>" or you will see the Bluetooth indicator glow solid white. **F**

Note: Visit owners.Bose.com/SoundLinkOE to see how-to videos (English only), or refer to your mobile device user guide to learn how it pairs/connects.

To change the voice prompt language

- With the headphones on your head, press and hold **C** and **+** together for five seconds. **C**
- Press the volume buttons to scroll through the list of available languages: When you hear the language you want, press and hold **+**.
- For additional languages, check updates.Bose.com/SoundLinkOE
 - To turn voice prompts off or on, press and hold **+** and **-** together.

Headphone controls **C**

- | | | |
|------------|------------------------------|--|
| + | Volume up | • Press once to play/pause or answer/end a call. |
| ••• | Multi-function button | • Double press to track forward. |
| - | Volume down | • Triple press to track back. |
| | | • Press and hold to ignore an incoming call. |
| | | • Press and hold to activate voice dial (Siri®). |

To add another device

Repeat Step 1 and Step 2 above for each new device.
The headphones can store eight devices in memory.
When powered on, the headphones will automatically connect to the first two devices in memory, for example a tablet for audio, and a phone for calls.

Managing devices

Slide up and release **D** to scroll through the list of devices in memory. **D** Repeat until you hear the device you want to control.

Note: If a device is not within Bluetooth range, 33 ft. (10 m), scroll to the next device.

Indicators

F	Blue blinking: Ready to pair White blinking: Connecting White solid: Connected
E	Green: Medium to full charge Amber: Low charge Red blinking: Need to charge

Charging

Plug the small end of the USB cable into the micro-USB connector on the right earcup. Plug the other end into a USB wall charger or computer that is powered on. **E**

Note: The headphones will not play while charging.

Using the back-up audio cable

Use the supplied back-up audio cable to connect a non-Bluetooth device, or if the headphones battery is depleted. **A**

Please refer to the Owner's Guide, available online, for more information about your headphones, including advanced functions, additional troubleshooting suggestions, and information on accessories and replacement parts. To request a printed copy of the complete Owner's Guide, please refer to the contact information on this sheet.

Troubleshooting

Headphones do not connect with mobile device

- On your device, turn off and on the Bluetooth functionality.
- Remove the headphones from the Bluetooth list on your mobile device. Then repeat steps 1-2 above.
- Try pairing another mobile device.
- Visit owners.Bose.com/SoundLinkOE to see how-to videos (English only).
- Clear the headphones memory:
Make sure **Bose OE SoundLink** is removed from the Bluetooth list on your mobile device. Slide up and hold **D** until you hear "device list cleared". Then repeat steps 1-2 above.

No sound

- Make sure the headphones power is on and battery is charged.
- Make sure the volume is turned up on the headphones and on your mobile device (or music app).
- Your mobile device may be connected to another Bluetooth speaker or headset. Make sure that **Bose OE SoundLink** is selected in the Bluetooth device list.

Poor sound quality

- Move the mobile device closer to the headphones, and away from any interference.

Technical Information

Operating time: 15 hours
Bluetooth range: 33 ft. (10 m)

iPad, iPhone, iPod, iPod touch, Retina and Siri are trademarks of Apple Inc., registered in the U.S. and other countries. iPad Air and iPad mini are trademarks of Apple Inc. The trademark "iPhone" is used with a license from Apple Inc.

"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone or iPad may affect wireless performance.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Bose Corporation is under license.
©2014 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

DANISH

GERMAN

DUTCH	SPANISH	FINNISH	FRENCH	ITALIAN	HUNGARIAN
				.	