

BOSE[®]

mobile in-ear headset

Owner's Guide
Brugervejledning
Bedienungsanleitung
Guía de usuario
Omistajan opas
Notice d'utilisation
Felhasználói útmutató
Manuale di istruzioni
Gebruiksaanwijzing
Podręcznik użytkownika
Bruksanvisningen

កម្មវិធីប្រើ

사용자 안내서

用户指南

دليل المالك



Welcome

Thank you for purchasing the Bose® mobile in-ear headset. The Bose® mobile in-ear headset offers a combination of lifelike audio performance and comfortable fit not available from most conventional earbuds.

Register your product


Now is a good time to register your headset. You can do this easily by going to <http://global.Bose.com>.



This product conforms to the EMC Directive 89/336/EEC. The complete Declaration of Conformity can be found at <http://www.Bose.com/compliance>.

WARNING: DO NOT use mobile phone adapters to connect headset to airplane seat jacks as this could result in personal injury such as burns or property damage due to overheating. Remove and disconnect immediately if you experience warming sensation or loss of audio.

©2009 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission. All trademarks referenced herein are property of Bose Corporation.



Connecting to a mobile phone or audio device

You can connect the headset to your mobile phone with either the 3.5 mm stereo plug (compatible with standard headphone jacks) or by using one of the three included 2.5mm adapter cables if needed.

The correct connection should allow:

- Stereo sound to be heard during music playback and communications
- Your voice to be heard by the person on the other end of a phone call
- The Answer/End button to operate as expected

Compatible with many music-enabled mobile phones. Refer to the enclosed compatibility list or visit www.Bose.com/phones for the latest list of compatible phones.

Without adapter

If your phone has a 3.5mm headphone/headset jack, you do not need to use the included adapters.

1. Plug the headset into the headphone/headset jack on the phone.
2. Put on the headset.




With adapter

The Bose® mobile in-ear headset includes three unique phone adapters. Each one is identified by a small symbol (circle, diamond, triangle) on the top of the plug.

If your phone has a 2.5mm headphone/headset jack, you will need to use one of these adapters.

Refer to www.Bose.com/phones to determine which adapter is compatible with your phone.



1. Select the appropriate adapter.
2. Attach the adapter to the headset cable
3. Plug the headset with the adapter into the headphone/headset jack on the phone.
4. Put on the headset.

Note: If your phone does not respond when you press the Answer/End button, you are getting partial or no sound, or the microphone is not picking-up sound, you may be using the wrong adapter. Refer to www.Bose.com/phones to determine which adapter is compatible with your phone.

Answering and ending calls

The Bose® mobile in-ear headset includes an easy to access Answer/End button with integrated microphone. Simply press the Answer/End button to perform an action.

Note: Some phones may require you to press and hold the Answer/End button for a few seconds to perform functions.

Answering calls

When you receive an incoming call, press and release the Answer/End button to answer.

Ending calls

When you are ready to end your call, press and release the Answer/End button.




Note: Some unique phone and music playback functions, like last number redial, voice commands, and track navigation are device-dependant, and may be accessible using the Answer/End button. Refer to your mobile phone user's manual to find out what features are available.

Using a single earpiece

The Bose® mobile in-ear headset can be used with only the right (R) earpiece in your ear. This allows you to take calls and still hear surrounding sounds.

Importance of Proper Fit

The Bose® mobile in-ear headset is designed to rest comfortably in the bowl of the ear. The soft silicone ear tip provides enough contact to secure the headset in place comfortably. Three sizes of ear tips are provided to help you customize the headset to your individual needs. **Do not** attempt to wear the headset without the ear tips.



Changing ear tips

Gently remove the existing ear tip by peeling up from its large rounded side. Slide the new ear tip over the nozzle of the headset. Press the ear tip securely into place until you feel it latch.



Adjusting for comfort and stability

There are several ways you can change your headset to provide additional comfort and stability. Using the adjustment slider, the clothing clip, and lanyard stability accessories, you can customize how you wear your headset.

Using the adjustment slider

Move the adjustment slider up or down to reduce or increase the amount of loose cord between the left and right earpiece. Finding the right position for the slider can help optimize the placement of the Answer/End button and integrated microphone.



Using the clothing clip

Use the clothing clip to fasten the cable to your clothing, for convenience, stability, and to help manage the cable. This can be helpful during high-movement activities or when using the headset in a single earpiece configuration.

The clothing clip should be attached below the Y-joint and be positioned to allow natural head movement, while keeping the microphone near your mouth.



Using the lanyard

The included lanyard provides additional stability to your headset. You can use the lanyard on its own, or with the clothing clip for even greater stability.

1. Attach the headset cord through the right (R) and left (L) lanyard connectors below the microphone and approximately 10 inches (25.4 cm) below each ear piece.

Make sure the L and R marks point up toward the ear pieces.

2. Pull the lanyard over your head and allow it to rest behind your neck.
3. Adjust the lanyard connectors so that any downward pulls on the plug end of the cord are not felt in the ears.



Note: Lanyard has a built-in safety release that separates when forcefully pulled.

Troubleshooting

If you experience any trouble using your headset, try the following troubleshooting instructions. If you still need help, see the contact information on the inside back cover for assistance in your area.

Problem	What to do
No audio/Intermittent	Make sure that the headset plug is securely connected to the headphone/headset jack (not the line out jack).
Sound is coming from only one earpiece	Make sure you are using the correct mobile phone adapter and that it is securely connected.
Incoming call ring tone not heard through headset	Make sure your phone is set to pass the ring tone through to the headset. Check your phone settings and make adjustments as needed. Note: <i>This feature may not be available on all phones.</i>
Excessive bass	Turn off any audio enhancement features on the audio source.
Low volume/poor audio	Turn off any "sound checker" or other audio signal altering features on the audio source.
Microphone is not picking-up sound	- Make sure you are using the correct mobile phone adapter and that it is securely connected. - Make sure the microphone is not being blocked or covered <i>The microphone is located on the back of the Answer/End button (you may notice the small opening for the microphone).</i>
Phone not responding when Answer/End button is pressed	Make sure you are using the correct mobile phone adapter and that it is securely connected. Note: <i>Some phones may require you to press and hold the Answer/End button for a few seconds to perform functions.</i>
Phone unexpectedly ends call	Some phones will end a call if the headset is unplugged during a call. Make sure that the headset plug is securely connected to the headphone/headset jack.
Ear tips falling off	Make sure the ear tips are securely attached to the housing.
Lost ear tip	Contact service representatives (on back page) to order replacements.
Sound is muffled from earpiece	Make sure ear tips and headset nozzles are clear of any debris or wax build-up.

Cleaning

Your headset may require periodic cleaning:

- Ear tips: First, remove them from the headset and wash the tips with a mild detergent and water. Make sure you thoroughly rinse and dry them before putting them back on the headset.
- Headset nozzles, Microphone, Answer/End button: Clean only with a dry, soft cotton swab or equivalent. Never insert any cleaning tool into the nozzle or microphone opening.
- Lanyard: Detach lanyard and wash with mild soap and water.

WARNINGS:

- *Contains small parts which may be a choking hazard. Not suitable for children under age 3.*
- *This product contains magnetic material.*
- *Long-term exposure to loud music may cause hearing damage. It is best to avoid high volume levels when using headphones, especially for extended periods.*
- *Except when used in single earpiece configuration, do not use this headset when operating a motor vehicle on a public road, or where the inability to hear outside sounds may present a danger to you or others.*

CAUTIONS:

- *Sounds that you rely on as reminders or warnings may have an unfamiliar character when using headphones. Be aware of how these sounds may vary in character so you can recognize them as needed.*
- *Do not drop, sit on, or allow the headset to be immersed in water.*

Limited Warranty

Your Bose® mobile in-ear headset is covered by a limited transferable warranty. Details of the limited warranty are provided on the product registration card that is included in the carton. Please refer to the card for instructions on how to register. Failure to register will not affect your limited warranty rights.

What you must do to obtain Limited Warranty Service:

Return product, with proof of purchase from an authorized Bose dealer, using the following procedures:

1. Visit <http://global.Bose.com> or contact your local authorized Bose dealer to identify the location of the nearest authorized Bose service facility;
2. Contact the authorized service facility for specific return and shipping instructions;
3. Label and ship the product, freight prepaid, to the address provided by the authorized service facility; and
4. Place any necessary return authorization number prominently on the outside of the carton. Cartons not bearing a return authorization number, where required, will be refused.



316835-0010

BOSE[®]
Better sound through research[®]

©2009 Bose Corporation, The Mountain,
Framingham, MA 01701-9168 USA
AM316835 Rev.02