

**Current Products (as of March 13, 2025)**

**Home Theater Systems**

Lifestyle® 500/600/650 (console)	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Wi-Fi: 1.6 W Ethernet: 2.0 W Bluetooth®: 1.6 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		2.0 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		<p>Wi-Fi: To deactivate Wi-Fi, press and hold the Source button on the console for 10 seconds. To reactivate Wi-Fi, press and hold the Source button on the console for 10 seconds.</p> <p>Bluetooth®: Deactivate by clearing the pairing list via the on-screen menu, the remote screen, or the SoundTouch application. Reactivate by pairing with a <i>Bluetooth</i>® source.</p>
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	S088AP44001252	PSM88W-213
	Input voltage	100V-240V	100V-240V
	Input AC frequency	50Hz/60Hz	50Hz/60Hz
	Output voltage	44V DC 10V DC	44V DC 10V DC
	Output current	1.3A 3.3A	1.3A 3.3A
	Output power	55W 33W	55W 33W
	Average active efficiency	88.6%	88.0%
	Efficiency at low load (10%)	87.2%	79.0%
	No-load power consumption	0.11W	0.17W

Home Theater  
Speakers

Acoustimass® 10 Series V home theater speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A
	Time after which equipment is automatically switched into mode	≤ 10 minutes	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

Bass Module 500 / Acoustimass wireless bass module	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Bose wireless: 0.47 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.47 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Per Annex II 3(a) of Regulation 801/2013 ("Lot 26" amendment of 1275/2008), the requirement to deactivate a wireless port "does not apply to products which rely on a single wireless network connection for intended use and have no wired network connection."

Bass Module 700 Acoustimass® 300 bass module	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Bose wireless: 0.6 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.6 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Per Annex II 3(a) of Regulation 801/2013 ("Lot 26" amendment of 1275/2008), the requirement to deactivate a wireless port "does not apply to products which rely on a single wireless network connection for intended use and have no wired network connection."

Home Theater  
Speakers

Smart Soundbar 300	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.40 W	Wi-Fi: 1.8 W Bluetooth®: 1.1 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.8 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	<p>Wi-Fi: Deactivate by pressing and holding the Mute/Unmute and <i>Bluetooth</i>® buttons on the remote until the light bar on the soundbar pulses white twice then fades to black. Repeat to reactivate.</p> <p>Bluetooth: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds. Activate by pairing with a <i>Bluetooth</i>® source.</p>	

Soundbar 500	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Wi-Fi: 1.2 W Ethernet: 1.7 W Bluetooth®: 1.2 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.6 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.*	<p>Wi-Fi: To deactivate Wi-Fi, press and hold the Bose Music and Skip Forward buttons on the remote simultaneously. Repeat to reactivate.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds. Reactivate by pairing with a <i>Bluetooth</i>® source.</p>	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT24V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	24V DC	
	Output current	1.9A	
	Output power	45W	
	Average active efficiency	89.9%	
	Efficiency at low load (10%)	87.0%	
	No-load power consumption	0.07W	

Home Theater  
Speakers

Smart Soundbar 600	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.38 W	Wi-Fi: 1.33 W Bluetooth®: 1.25 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.35 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.*			<p>Wi-Fi: Activate using the Bose Music app. Deactivate by pressing and holding the Mute and <i>Bluetooth</i>® buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate by pairing with a <i>Bluetooth</i>® source by pressing the <i>Bluetooth</i>® button on the remote then selecting the soundbar in your mobile device <i>Bluetooth</i>® list or by pressing the Bose Music app. Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds.</p>

Smart Soundbar 700	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.49 W	Wi-Fi: 1.4 W Ethernet: 1.8 W Bluetooth®: 1.4 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.8 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.*			<p>Wi-Fi: To deactivate Wi-Fi, press and hold the Bose Music and Skip Forward buttons on the remote simultaneously. Repeat to reactivate.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds. Reactivate by pairing with a Bluetooth® source.</p>
* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).			

Smart Soundbar 900	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.47 W	Wi-Fi: 1.8 W Ethernet: 1.9 W Bluetooth®: 1.8 W HDMI: 1.8 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.9 W
Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.*			<p>Wi-Fi: Activate Wi-Fi by setting up the soundbar via the Bose Music app. Deactivate Wi-Fi by pressing and holding the Bose Music and Skip Forward buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate <i>Bluetooth</i>® by pairing a source to the soundbar. Deactivate <i>Bluetooth</i>® by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds.</p>
* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).			

Home Theater  
Speakers

Bose Smart Ultra Soundbar	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.44 W	Wi-Fi: 1.24 W Ethernet: 1.49 W Bluetooth®: 1.16 W HDMI: 1.60 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.9 W
Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.*		Wi-Fi: Activate Wi-Fi by setting up the soundbar via the Bose Music app. Deactivate Wi-Fi by pressing and holding mute and bluetooth buttons on the remote simultaneously for 3 seconds.	
* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).		Bluetooth®: Activate <i>Bluetooth</i> ® by pairing a source to the soundbar. Deactivate <i>Bluetooth</i> by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the remote for 10 seconds.	
Bose Smart Soundbar	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.48 W	Wi-Fi: 1.20 W Bluetooth®: 1.36W HDMI: 1.60 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.9 W
Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.*		Wi-Fi: Activate Wi-Fi by setting up the soundbar via the Bose Music app. Deactivate Wi-Fi by pressing and holding mute and bluetooth buttons on the remote simultaneously for 3 seconds.	
* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).		Bluetooth®: Activate <i>Bluetooth</i> ® by pairing a source to the soundbar. Deactivate <i>Bluetooth</i> by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the remote for 10 seconds.	

Home Theater Speakers

Surround Speakers	Power State Information	Power Modes	
		Standby	Networked Standby
Virtually Invisible® 300 wireless surround speakers	Power consumption in specified power mode, at 230V/50Hz input	0.46 W	Bose wireless: 0.9 W
Virtually Invisible® 300/Surround Speakers 700	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.9 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Per Annex II 3(a) of Regulation 801/2013 ("Lot 26" amendment of 1275/2008), the requirement to deactivate a wireless port "does not apply to products which rely on a single wireless network connection for intended use and have no wired network connection."	

TV Speaker	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.28 W	Bluetooth: 1.7 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.7 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the remote until the <i>Bluetooth</i> ® indicator blinks blue. Reactivate by pairing with a <i>Bluetooth</i> ® source.	

Home Theater Speakers

Solo 5 TV sound system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.2 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 1 hour	N/A*
	wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
External Power Supply Specifications	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection	
	Manufacturer, commercial registration number,	Bose Products B.V. 36037901	
	Model identifier	DT20V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	20V DC	
	Output current	1.8A	
	Output power	36W	
	Average active efficiency	89.0%	
	Efficiency at low load (10%)	88.3%	
	No-load power consumption	0.08W	

**Wave Music  
Systems**

<b>Wave® music system IV</b>	<b>Power State Information</b>	<b>Power Modes</b>	
		<b>Standby</b>	<b>Networked Standby</b>
	Power consumption in specified power mode, at 230V/50Hz input	0.97 W	N/A
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

**Multimedia  
Sound**

Home Speaker 300	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	<p>Power consumption in specified power mode, at 230V/50Hz input</p> <p>Time after which equipment is automatically switched into mode</p> <p>wired network ports connected and all wireless network ports activated, at 230V/50Hz input</p> <p>Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.</p>	<p>0.34 W</p> <p>≤ 2.5 hours</p>	<p>Wi-Fi: 1.4 W</p> <p>Bluetooth®: 0.8 W</p> <p>≤ 20 minutes</p>
External Power Supply Specifications	Manufacturer, commercial registration number, address	<p>1.4 W</p> <p>Wi-Fi®: Deactivate by pressing and holding the Play/Pause and <i>Bluetooth</i>® buttons simultaneously for at least 5 seconds. Repeat to activate.</p>	
	Model identifier	<p>Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands</p>	
	Input voltage	F24V-0.9C-DC-WW	
	Input AC frequency	100V-240V	
	Output voltage	50Hz/60Hz	
	Output current	24V DC	
	Output power	0.9A	
	Average active efficiency	21.6W	
	Efficiency at low load (10%)	87.2%	
	No-load power consumption	82.7%	
		0.07W	

**Multimedia  
Sound**

Home Speaker 500 Smart Speaker 500	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.47 W	Wi-Fi: 1.7 W Bluetooth®: 1.3 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.7 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Wi-Fi®: Deactivate by pressing and holding the Play/Pause and Bluetooth® buttons simultaneously for at least 5 seconds. Repeat to activate.	

Portable Home Speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Wi-Fi: 1.2 W Bluetooth®: 0.7 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.2 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Wi-Fi®: Deactivate by pressing and holding the Play/Pause and Bluetooth® buttons simultaneously for at least 5 seconds. Repeat to activate.	
		Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the Bluetooth® button for 10 seconds. Activate by pairing with a Bluetooth® source.	
External Power Supply Specifications	Manufacturer, commercial registration number,	Bose Products B.V. 36037901	
	Model identifier	F5V-3C-TC-WW	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	5V DC	
	Output current	3A	
	Output power	15W	
	Average active efficiency	82.3%	
	Efficiency at low load (10%)	76.0%	
	No-load power consumption	0.07W	

**Multimedia  
Sound**

Companion® 2 Series III multimedia speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.2 W	N/A
	Time after which equipment is automatically switched into mode	≤ 2 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A
External Power Supply Specifications	Manufacturer, commercial registration number,	Bose Products B.V. 36037901	
	Model identifier	ITC12V-1.35C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	12V DC	
	Output current	1.35A	
	Output power	16.2W	
	Average active efficiency	86.7%	
	Efficiency at low load (10%)	80.9%	
	No-load power consumption	0.09W	

**Multimedia  
Sound**

Companion® 20 multimedia speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	N/A
	Time after which equipment is automatically switched into mode	≤ 30 minutes	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A
External Power Supply Specifications	Manufacturer, commercial registration number,	Bose Products B.V. 36037901	
	Model identifier	DT20V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	20V DC	
	Output current	1.8A	
	Output power	36W	
	Average active efficiency	89.0%	
	Efficiency at low load (10%)	88.3%	
No-load power consumption	0.08W		

**Multimedia  
Sound**

Companion® 50 multimedia speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.48 W	N/A
	Time after which equipment is automatically switched into mode	≤ 30 minutes	N/A
	wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

SoundLink® Revolve Bluetooth® speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	0.4 W
	Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 1 minute
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.4 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the unit for 10 seconds. Reactivate by pairing with a <i>Bluetooth</i> ® source.	
External Power Supply Specifications	Manufacturer, commercial registration number,	Bose Products B.V. 36037901	
	Model identifier	F5V-1.6C-1U-WW	S008AIM0500160
	Input voltage	100V-240V	100V-240V
	Input AC frequency	50Hz/60Hz	50Hz/60Hz
	Output voltage	5V DC	5V DC
	Output current	1.6A	1.6A
	Output power	8W	8W
	Average active efficiency	78.8%	78.5%
	Efficiency at low load (10%)	73.4%	74.5%
	No-load power consumption	0.07W	0.06W

**Multimedia  
Sound**

**SoundLink® Revolve+, Revolve+ II Bluetooth® speaker**

**Power State Information**

**Power Modes**

Product Specifications	Power State Information	Standby	Networked Standby
		<p>Power consumption in specified power mode, at 230V/50Hz input</p> <p>Time after which equipment is automatically switched into mode</p> <p>wired network ports connected and all wireless network ports activated, at 230V/50Hz input</p> <p>Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.</p>	<p>0.3 W</p> <p>≤ 20 minutes</p>
		0.4 W	
		Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the unit for 10 seconds. Reactivate by pairing with a <i>Bluetooth</i> ® source.	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	F5V-1.6C-1U-WW	S008AIM0500160
	Input voltage	100V-240V	100V-240V
	Input AC frequency	50Hz/60Hz	50Hz/60Hz
	Output voltage	5V DC	5V DC
	Output current	1.6A	1.6A
	Output power	8W	8W
	Average active efficiency	78.8%	78.5%
	Efficiency at low load (10%)	73.4%	74.5%
	No-load power consumption	0.07W	0.06W

**Multimedia  
Sound**

SoundTouch 10 wireless music system	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.3 W	Wi-Fi: 1.8 W Bluetooth®: 1.9 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.8 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi: To deactivate Wi-Fi, press and hold "3" and volume down on the button pad until the Wi-Fi indicator turns off. To reactivate Wi-Fi, press and hold "3" and volume down until the Wi-Fi indicator is illuminated.	

SoundTouch™ 20 wireless speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.4 W	Wi-Fi: 1.6 W Bluetooth®: 1.8 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.6 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi: To deactivate Wi-Fi, press and hold "3" and volume down on the button pad until the Wi-Fi indicator turns off. To reactivate Wi-Fi, press and hold "3" and volume down until the Wi-Fi indicator is illuminated.	
		Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the unit until a confirmation message appears on the display. Reactivate by pairing with a <i>Bluetooth</i> ® source.	

---

Multimedia Sound	<b>SoundTouch™ 30 wireless speaker</b>	<b>Power State Information</b>		<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>	
		Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Wi-Fi: 1.6 W Bluetooth®: 1.8 W	
		Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes	
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.6 W		
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi: To deactivate Wi-Fi, press and hold "3" and volume down on the button pad until the Wi-Fi indicator turns off. To reactivate Wi-Fi, press and hold "3" and volume down until the Wi-Fi indicator is illuminated.		

Live Music	<b>S1 Pro Multi-Position PA System</b>	<b>Power State Information</b>		<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>	
		Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A*	
		Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*	
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*		
	Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.		*Product does not utilize a networked standby mode for a Bluetooth® connection		

	<b>S1 Pro+ Multi-Position PA System</b>	<b>Power State Information</b>		<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>	
		Power consumption in specified power mode, at 230V/50Hz input	0.395 W	N/A*	
		Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*	
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*		
	Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.		*Product does not utilize a networked standby mode for a Bluetooth® connection		

	<b>L1 Pro8 Portable Line Array System</b>	<b>Power State Information</b>		<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>	
		Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A*	
		Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*	
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*		
	Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.		*Product does not utilize a networked standby mode for a Bluetooth® connection		

Live Music

L1 Pro16 Portable Line Array System	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection

L1 Pro32 Portable Line Array System	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection

Professional Products

Sub1 Powered Bass Module	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.2 W	N/A
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

**Professional  
Products**

Sub2 Powered Bass Module	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

Videobar VB1	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Wi-Fi: 1.9 W Ethernet: 1.9 W Bluetooth®: 1.9 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.9 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds, or simultaneously press and hold the Mute and <i>Bluetooth</i> ® buttons on the side of the unit for 5 seconds. Activate via the compatible application.
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT24V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	24V DC	
	Output current	1.9A	
	Output power	45W	
	Average active efficiency	89.9%	
	Efficiency at low load (10%)	87.0%	
	No-load power consumption	0.07W	

**Professional  
Products**

Videobar VB-S	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.43 W	Wi-Fi: 1.47 W Ethernet: 1.47 W Bluetooth®: 1.47 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.47 W
	Network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Wi-Fi: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds.  Bluetooth®: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds.	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT24V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	24V DC	
	Output current	1.9A	
	Output power	45W	
	Average active efficiency	89.9%	
	Efficiency at low load (10%)	87.0%	
	No-load power consumption	0.07W	

Accessories

SoundTouch® wireless link adapter	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Wi-Fi: 1.4 W Bluetooth®: 1.6 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input	1.4 W	
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Wi-Fi and Bluetooth®: To deactivate the networks, press and hold the Control button on the back of the unit until the Wi-Fi and Bluetooth® indicators turn off. To reactivate the networks, press the Control button until the indicators turn on.	
		Bluetooth® only: Deactivate by clearing the pairing list by pressing Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
External Power Supply Specifications	Manufacturer, commercial registration number, address	AFD5V-1C-DC-WD	
	Model identifier	100V-240V	
	Input voltage	50Hz/60Hz	
	Input AC frequency	5V DC	
	Output voltage	1A	
	Output current	5W	
	Output power	74.8%	
	Average active efficiency	68.4%	
	Efficiency at low load (10%)	0.06W	
	No-load power consumption		

Amplifiers

SoundTouch™ SA-5 amplifier	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at		0.3 W	Wi-Fi: 1.4 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi and Bluetooth®: To deactivate networks, press and hold the unit's Control button. When the Wi-Fi indicator turns off, release the Control button. To reactivate the networks, press the unit's Control button.	
Bose Music Amplifier	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		≤ 0.46 W	Wi-Fi: 2.64 W Ethernet: 2.44 W Bluetooth®: 2.03 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			2.41 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi: To deactivate, insert a thin paperclip into the hole in the back of the amplifier and press and hold for 2 seconds until the light on the back of the amplifier blinks white 3 times.  Bluetooth®: To deactivate, clear the <i>Bluetooth</i> ® pairing list. Press and hold the <i>Bluetooth</i> ® button on the amplifier for 10 seconds. To reactivate, connect a <i>Bluetooth</i> ® source.	