

**Current Products (as of April 4, 2023)**

**Home Theater Systems**

Lifestyle® 500/600/650 (console)	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Wi-Fi: 1.6 W Ethernet: 2.0 W Bluetooth®: 1.6 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		2.0 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		<p>Wi-Fi: To deactivate Wi-Fi, press and hold the Source button on the console for 10 seconds. To reactivate Wi-Fi, press and hold the Source button on the console for 10 seconds.</p> <p>Bluetooth®: Deactivate by clearing the pairing list via the on-screen menu, the remote screen, or the SoundTouch application. Reactivate by pairing with a <i>Bluetooth</i>® source.</p>
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	S088AP44001252	PSM88W-213
	Input voltage	100V-240V	100V-240V
	Input AC frequency	50Hz/60Hz	50Hz/60Hz
	Output voltage	44V DC 10V DC	44V DC 10V DC
	Output current	1.3A 3.3A	1.3A 3.3A
	Output power	55W 33W	55W 33W
	Average active efficiency	88.6%	88.0%
	Efficiency at low load (10%)	87.2%	79.0%
	No-load power consumption	0.11W	0.17W

Home Theater  
Speakers

Acoustimass® 10 Series V home theater speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A
	Time after which equipment is automatically switched into mode	≤ 10 minutes	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

Bass Module 500 / Acoustimass wireless bass module	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Bose wireless: 0.47 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.47 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Per Annex II 3(a) of Regulation 801/2013 ("Lot 26" amendment of 1275/2008), the requirement to deactivate a wireless port "does not apply to products which rely on a single wireless network connection for intended use and have no wired network connection."

Bass Module 700 Acoustimass® 300 bass module	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Bose wireless: 0.6 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.6 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Per Annex II 3(a) of Regulation 801/2013 ("Lot 26" amendment of 1275/2008), the requirement to deactivate a wireless port "does not apply to products which rely on a single wireless network connection for intended use and have no wired network connection."

Home Theater  
Speakers

Smart Soundbar 300	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.40 W	Wi-Fi: 1.8 W Bluetooth®: 1.1 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.8 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		<p>Wi-Fi: Deactivate by pressing and holding the Mute/Unmute and <i>Bluetooth</i>® buttons on the remote until the light bar on the soundbar pulses white twice then fades to black. Repeat to reactivate.</p> <p>Bluetooth: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds. Activate by pairing with a <i>Bluetooth</i>® source.</p>

Soundbar 500	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	Wi-Fi: 1.2 W Ethernet: 1.7 W Bluetooth®: 1.2 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.6 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.*		<p>Wi-Fi: To deactivate Wi-Fi, press and hold the Bose Music and Skip Forward buttons on the remote simultaneously. Repeat to reactivate.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds. Reactivate by pairing with a <i>Bluetooth</i>® source.</p>
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT24V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	24V DC	
	Output current	1.9A	
	Output power	45W	
	Average active efficiency	89.9%	
	Efficiency at low load (10%)	87.0%	
No-load power consumption	0.07W		

Home Theater  
Speakers

Smart Soundbar 600	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.38 W	Wi-Fi: 1.33 W Bluetooth®: 1.25 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.35 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.*			<p>Wi-Fi: Activate using the Bose Music app. Deactivate by pressing and holding the Mute and <i>Bluetooth</i>® buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate by pairing with a <i>Bluetooth</i>® source by pressing the <i>Bluetooth</i>® button on the remote then selecting the soundbar in your mobile device <i>Bluetooth</i>® list or by pressing the Bose Music app. Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds.</p>

Home Theater  
Speakers

Smart Soundbar 700	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.49 W	Wi-Fi: 1.4 W Ethernet: 1.8 W Bluetooth®: 1.4 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.8 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.*			<p>Wi-Fi: To deactivate Wi-Fi, press and hold the Bose Music and Skip Forward buttons on the remote simultaneously. Repeat to reactivate.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds. Reactivate by pairing with a Bluetooth® source.</p>
* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).			

Smart Soundbar 900	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.47 W	Wi-Fi: 1.8 W Ethernet: 1.9 W Bluetooth®: 1.8 W HDMI: 1.8 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.9 W
Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.*			<p>Wi-Fi: Activate Wi-Fi by setting up the soundbar via the Bose Music app. Deactivate Wi-Fi by pressing and holding the Bose Music and Skip Forward buttons on the remote simultaneously.</p> <p>Bluetooth®: Activate <i>Bluetooth</i>® by pairing a source to the soundbar. Deactivate <i>Bluetooth</i> by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the remote for 10 seconds.</p>
* Prior to deactivating networks or entering standby mode, use the microphone on/off button to ensure the microphone is turned on (the red indicator light will be off).			

Surround Speakers	Power State Information	Power Modes	
		Standby	Networked Standby
<b>Virtually Invisible® 300 wireless surround speakers</b>	Power consumption in specified power mode, at 230V/50Hz input	0.46 W	Bose wireless: 0.9 W
<b>Virtually Invisible® 300/Surround Speakers 700</b>	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.9 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Per Annex II 3(a) of Regulation 801/2013 ("Lot 26" amendment of 1275/2008), the requirement to deactivate a wireless port "does not apply to products which rely on a single wireless network connection for intended use and have no wired network connection."	

**Home Theater  
Speakers**

TV Speaker	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.28 W	Bluetooth: 1.7 W
	Time after which equipment is automatically switched into mode	≤ 2 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.7 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the remote until the <i>Bluetooth</i> ® indicator blinks blue. Reactivate by pairing with a <i>Bluetooth</i> ® source.	

Solo 5 TV sound system		Power Modes	
Product Specifications	Power State Information	Standby	Networked Standby
			Power consumption in specified power mode, at 230V/50Hz input
	Time after which equipment is automatically switched into mode	≤ 1 hour	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT20V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	20V DC	
	Output current	1.8A	
	Output power	36W	
	Average active efficiency	89.0%	
	Efficiency at low load (10%)	88.3%	
	No-load power consumption	0.08W	

**Wave Music  
Systems**

<b>Wave® music system IV</b>	<b>Power State Information</b>	<b>Power Modes</b>	
		<b>Standby</b>	<b>Networked Standby</b>
	Power consumption in specified power mode, at 230V/50Hz input	0.97 W	N/A
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

**Multimedia  
Sound**

	<b>Home Speaker 300</b>	<b>Power State Information</b>	<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>
Product Specifications		Power consumption in specified power mode, at 230V/50Hz input	0.34 W	Wi-Fi: 1.4 W Bluetooth®: 0.8 W
		Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
		Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.4 W
		Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi®: Deactivate by pressing and holding the Play/Pause and <i>Bluetooth</i> ® buttons simultaneously for at least 5 seconds. Repeat to activate.  Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button for 10 seconds. Activate by pairing with a <i>Bluetooth</i> ® source.
External Power Supply Specifications		Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
		Model identifier	F24V-0.9C-DC-WW	
		Input voltage	100V-240V	
		Input AC frequency	50Hz/60Hz	
		Output voltage	24V DC	
		Output current	0.9A	
		Output power	21.6W	
		Average active efficiency	87.2%	
		Efficiency at low load (10%)	82.7%	
			No-load power consumption	0.07W

	<b>Home Speaker 500</b>	<b>Power State Information</b>	<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>
Smart Speaker 500		Power consumption in specified power mode, at 230V/50Hz input	0.47 W	Wi-Fi: 1.7 W Bluetooth®: 1.3 W
		Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
		Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.7 W
		Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		Wi-Fi®: Deactivate by pressing and holding the Play/Pause and <i>Bluetooth</i> ® buttons simultaneously for at least 5 seconds. Repeat to activate.  Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button for 10 seconds. Activate by pairing with a <i>Bluetooth</i> ® source.



**Multimedia  
Sound**

Portable Home Speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Wi-Fi: 1.2 W Bluetooth®: 0.7 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.2 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	<p>Wi-Fi®: Deactivate by pressing and holding the Play/Pause and <i>Bluetooth</i>® buttons simultaneously for at least 5 seconds. Repeat to activate.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button for 10 seconds. Activate by pairing with a <i>Bluetooth</i>® source.</p>	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	F5V-3C-TC-WW	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	5V DC	
	Output current	3A	
	Output power	15W	
	Average active efficiency	82.3%	
	Efficiency at low load (10%)	76.0%	
	No-load power consumption	0.07W	

**Multimedia  
Sound**

	<b>Companion® 2 Series III multimedia speaker system</b>	<b>Power State Information</b>	<b>Power Modes</b>	
			<b>Standby</b>	<b>Networked Standby</b>
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input		0.2 W	N/A
	Time after which equipment is automatically switched into mode		≤ 2 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.			N/A
External Power Supply Specifications	Manufacturer, commercial registration number, address		Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier		ITC12V-1.35C-DC	
	Input voltage		100V-240V	
	Input AC frequency		50Hz/60Hz	
	Output voltage		12V DC	
	Output current		1.35A	
	Output power		16.2W	
	Average active efficiency		86.7%	
	Efficiency at low load (10%)		80.9%	
	No-load power consumption		0.09W	

**Multimedia  
Sound**

Companion® 20 multimedia speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	N/A
	Time after which equipment is automatically switched into mode	≤ 30 minutes	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT20V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	20V DC	
	Output current	1.8A	
	Output power	36W	
	Average active efficiency	89.0%	
	Efficiency at low load (10%)	88.3%	
	No-load power consumption	0.08W	

Companion® 50 multimedia speaker system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.48 W	N/A
	Time after which equipment is automatically switched into mode	≤ 30 minutes	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

**Multimedia  
Sound**

SoundLink® Revolve Bluetooth® speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	0.4 W
	Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 1 minute
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.4 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the unit for 10 seconds. Reactivate by pairing with a <i>Bluetooth</i> ® source.	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	F5V-1.6C-1U-WW	S008AIM0500160
	Input voltage	100V-240V	100V-240V
	Input AC frequency	50Hz/60Hz	50Hz/60Hz
	Output voltage	5V DC	5V DC
	Output current	1.6A	1.6A
	Output power	8W	8W
	Average active efficiency	78.8%	78.5%
	Efficiency at low load (10%)	73.4%	74.5%
	No-load power consumption	0.07W	0.06W

**Multimedia  
Sound**

SoundLink® Revolve+, Revolve+ II Bluetooth® speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	0.4 W
	Time after which equipment is automatically switched into mode	≤ 20 minutes	≤ 1 minute
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		0.4 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the unit for 10 seconds. Reactivate by pairing with a <i>Bluetooth</i> ® source.	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	F5V-1.6C-1U-WW	S008AIM0500160
	Input voltage	100V-240V	100V-240V
	Input AC frequency	50Hz/60Hz	50Hz/60Hz
	Output voltage	5V DC	5V DC
	Output current	1.6A	1.6A
	Output power	8W	8W
	Average active efficiency	78.8%	78.5%
	Efficiency at low load (10%)	73.4%	74.5%
	No-load power consumption	0.07W	0.06W

SoundTouch 10 wireless music system	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Wi-Fi: 1.8 W Bluetooth®: 1.9 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.8 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	Wi-Fi: To deactivate Wi-Fi, press and hold "3" and volume down on the button pad until the Wi-Fi indicator turns off. To reactivate Wi-Fi, press and hold "3" and volume down until the Wi-Fi indicator is illuminated.  Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i> ® button on the unit until the <i>Bluetooth</i> ® indicator blinks white. Reactivate by pairing with a <i>Bluetooth</i> ® source.	

**Multimedia  
Sound**

SoundTouch™ 20 wireless speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.4 W	Wi-Fi: 1.6 W Bluetooth®: 1.8 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.6 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.			<p>Wi-Fi: To deactivate Wi-Fi, press and hold "3" and volume down on the button pad until the Wi-Fi indicator turns off. To reactivate Wi-Fi, press and hold "3" and volume down until the Wi-Fi indicator is illuminated.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the unit until a confirmation message appears on the display. Reactivate by pairing with a <i>Bluetooth</i>® source.</p>

SoundTouch™ 30 wireless speaker	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.4 W	Wi-Fi: 1.6 W Bluetooth®: 1.8 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.6 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.			<p>Wi-Fi: To deactivate Wi-Fi, press and hold "3" and volume down on the button pad until the Wi-Fi indicator turns off. To reactivate Wi-Fi, press and hold "3" and volume down until the Wi-Fi indicator is illuminated.</p> <p>Bluetooth®: Deactivate by clearing the pairing list by pressing and holding the <i>Bluetooth</i>® button on the unit until a confirmation message appears on the display. Reactivate by pairing with a <i>Bluetooth</i>® source.</p>

Live Music

S1 Pro Multi-Position PA System	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.	*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection	

L1 Pro8 Portable Line Array System	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port activation/deactivation procedures. Deactivating all networks will enable standby mode.	*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection	

L1 Pro16 Portable Line Array System	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection	

Live Music

L1 Pro32 Portable Line Array System	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.4 W	N/A*
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A*
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A*
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	*Product does not utilize a networked standby mode for a <i>Bluetooth</i> ® connection	

Sub1 Powered Bass Module	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.2 W	N/A
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A

Sub2 Powered Bass Module	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	N/A
	Time after which equipment is automatically switched into mode	≤ 4 hours	N/A
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		N/A
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		N/A



**Professional  
Products**

Videobar VB1	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.3 W	Wi-Fi: 1.9 W Ethernet: 1.9 W Bluetooth®: 1.9 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.9 W
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		<p>Wi-Fi: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds, or simultaneously press and hold the Mute and <i>Bluetooth</i>® buttons on the side of the unit for 5 seconds. Activate via the compatible application.</p> <p>Bluetooth®: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds, or simultaneously press and hold the Mute and <i>Bluetooth</i>® buttons on the side of the unit for 5 seconds. Activate by pairing with a <i>Bluetooth</i>® source.</p>
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT24V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	24V DC	
	Output current	1.9A	
	Output power	45W	
	Average active efficiency	89.9%	
	Efficiency at low load (10%)	87.0%	
	No-load power consumption	0.07W	

**Professional  
Products**

Videobar VB-S	Power State Information	Power Modes	
		Standby	Networked Standby
Product Specifications	Power consumption in specified power mode, at 230V/50Hz input	0.43 W	Wi-Fi: 1.47 W Ethernet: 1.47 W Bluetooth®: 1.47 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input		1.47 W
	Network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	<p>Wi-Fi: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds.</p> <p>Bluetooth®: Deactivate by restoring the factory default settings: simultaneously press and hold the Home and Autoframe buttons on the remote for 5 seconds.</p>	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	DT24V-1.8C-DC	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	24V DC	
	Output current	1.9A	
	Output power	45W	
	Average active efficiency	89.9%	
	Efficiency at low load (10%)	87.0%	
	No-load power consumption	0.07W	

**Accessories**

SoundTouch® wireless link adapter	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.3 W	Wi-Fi: 1.4 W Bluetooth®: 1.6 W
Time after which equipment is automatically switched into mode		≤ 2 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			1.4 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		<p>Wi-Fi and Bluetooth®: To deactivate the networks, press and hold the Control button on the back of the unit until the Wi-Fi and Bluetooth® indicators turn off. To reactivate the networks, press the Control button until the indicators turn on.</p> <p>Bluetooth® only: Deactivate by clearing the pairing list by pressing and holding the Bluetooth® button on the unit for 10 seconds. Reactivate by pairing with a Bluetooth® source.</p>	
External Power Supply Specifications	Manufacturer, commercial registration number, address	Bose Products B.V. 36037901 Gorslaan 60 1441 RG Purmerend The Netherlands	
	Model identifier	AFD5V-1C-DC-WD	
	Input voltage	100V-240V	
	Input AC frequency	50Hz/60Hz	
	Output voltage	5V DC	
	Output current	1A	
	Output power	5W	
	Average active efficiency	74.8%	
	Efficiency at low load (10%)	68.4%	
	No-load power consumption	0.06W	

**Amplifiers**

SoundTouch™ SA-5 amplifier	Power State Information	Power Modes	
		Standby	Networked Standby
Power consumption in specified power mode, at 230V/50Hz input		0.3 W	Wi-Fi: 1.4 W Ethernet: 2.0 W Bluetooth®: 1.5 W
Time after which equipment is automatically switched into mode		≤ 2.5 hours	≤ 20 minutes
Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input			2.0 W
Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.		<p>Wi-Fi and Bluetooth®: To deactivate networks, press and hold the unit's Control button. When the Wi-Fi indicator turns off, release the Control button. To reactivate the networks, press the unit's Control button.</p>	

**Amplifiers**

Bose Music Amplifier	Power State Information	Power Modes	
		Standby	Networked Standby
	Power consumption in specified power mode, at 230V/50Hz input	≤ 0.46 W	Wi-Fi: 2.64 W Ethernet: 2.44 W Bluetooth®: 2.03 W
	Time after which equipment is automatically switched into mode	≤ 2.5 hours	≤ 20 minutes
	Power consumption in networked standby with all wired network ports connected and all wireless network ports activated, at 230V/50Hz input	2.41 W	
	Wireless network port deactivation/activation procedures. Deactivating all networks will enable standby mode.	<p>Wi-Fi: To deactivate, insert a thin paperclip into the hole in the back of the amplifier and press and hold for 2 seconds until the light on the back of the amplifier blinks white 3 times.</p> <p>Bluetooth®: To deactivate, clear the <i>Bluetooth</i>® pairing list. Press and hold the <i>Bluetooth</i>® button on the amplifier for 10 seconds. To reactivate, connect a <i>Bluetooth</i>® source.</p>	